



NOTES:

1. SIGNAGE BY OTHERS.
2. SAW CUT NORTH CURB AND REMOVE AT LOCATIONS SHOWN.
3. EROSION CONTROL REQUIRED APPROXIMATELY AS SHOWN.
4. SAW CUT LOCATIONS TO BE MARKED BY ENGINEER.
5. DRAINAGE PIPE ELEVATIONS APPROXIMATE; INSTALL TO DRAIN.
6. LANDSCAPE AREAS WITHIN PARKING LOT RAISED TO APPROXIMATELY 18 INCHES ABOVE PARKING LOT GRADE, GRADED TO DRAIN.
7. INSTALL 6 IN. X 6 IN. TREATED POSTS WITH CONTINUOUS 1/2 IN. Ø CABLE FOR BARRICADES 1 FT. FROM EDGE OF PAVEMENT AT LOCATIONS SHOWN. MAX. SPACING OF POSTS IS 8 FT. SEE DETAIL.
8. INSTALL BROWN HARDWOOD MULCH AT LANDSCAPE AREAS AS SHOWN, 6 IN. DEPTH.
9. INSTALL LARGE RIVER ROCK, 4 IN. DEPTH, ALONG 3 FT. STRIP ADJACENT TO PARKING AREAS, AS SHOWN.



POST & CABLE BARRIER (EXAMPLE)

- POST & CABLE BARRIER
- - - 6 IN. UNDERDRAIN
- ✱ ORNAMENTAL GRASSES
- ◯ TREE